
JS-B1101

- Before assembling, all parts should be clean, no oil or grease, remove all burrs and sharp edges.
- 2.Before connecting, body cap male thread should be coated with sealing glue.
- 3. Handle turn or close freely.
- 4.After assembling, test by water at pressure no less than 0.6MPA, no leakage.

NO	Name	Material
1	Body	BRASS
2	Bonnet	BRASS
3	Gasket	Heat resisting fiber
4	wedge	BRASS
5	Stem	BRASS
6	Screwed ring	BRASS
7	Packing	PTFE
8	Packing nut	BRASS
9	Handwheel	STEEL
10	Nut	STEEL






DN	A	В			D
1/2"	15	10	43	68	45
3/4"	19	11	47	78	50
1"	24	13	53	93	55
1-1/4"	32	14	57	108	60
1-1/2"	37	14	61	125	70
2"	47	16	67	143	80
2-1/2"	60	17	74	175	100
3"	72	19	86	205	100
4"	93	22	98	235	120



DN		В	L		D
1/2"	13	13	45.5	82	55.5
3/4"	19	13	48	97	60
1	24	14	52	108	65
1-1/4"	31	16,5	60	121	74.5
1-1/2"	35	16.5	62	138	80
2"	46	18.5	70	147	90
3*	65	21	81	208	120
4"	90	26	98	260	141






JS-B1102

- Before assembling, all parts should be clean, no oil or grease, remove all burrs and sharp edges.
- $2. \\ Before connecting, body cap male thread should \\ be coated with sealing glue \ .$
- 3. Handle turn or close freely.
- 4.After assembling, test by water at pressure no less than 0.8MPA, no leakage.

NO.	Name	Material
1	Body	BRASS
2	Wedge	BRASS
3	Bonnet	BRASS
4	Washer	Red paper gasket
5	Stem	BRASS
6	Screwed ring	BRASS
7	Packing	PTFE
8	Brass gasket	BRASS
9	Press nut	BRASS
10	Handwheel	AL
11	Washer	AL
12	Nut	STEEL



	Name	
1	Body	BRASS
2	Board	BRASS
3	Gasket	PTFE
4	Bonnet	BRASS
5	Screwed ring	BRASS
6	Stem	BRASS
7	Packing	PTFE
8	Packing nut	BRASS
9	Washer	BRASS
10	Handwheel	Cast Iron
11	Washer	AL
12	Nut	STEEL



JS-B1106

- 1.Before assembling, all parts should be clean, no oil or grease, remove all burrs and sharp edges.
- 2.Before connecting, body cap male thread should be coated with sealing glue.
- 3. Handle turn or close freely.
- 4.After assembling, test by water at pressure no less than 0.8MPA, no leakage.

DN	A	В	L	H	D
1/2"	13	11.5	42	75	50
3/4"	19	12	47	85	55
1"	24	12.5	50	95	61
1-1/4"	30	16	58	115	68
1-1/2"	36	18	64	125	78
2"	44	22	76	142	85


DN	A	В	L	
1/2"	13	14.5	57	35
3/4"	18	15	60	39
1"	23.5	18	68	44
1-1/4"	18	16	78.5	49
1-1/2"	30	22	90	58.5
2"	42	23	102	68
2-1/2"	52	21	118	82
37	66	25	133.3	84
4"	90	28	179.5	106

JS-C1101

- Before assembling, all parts should be clean, no oil or grease, remove all burrs and sharp edges.
- 2.Before connecting, body cap male thread should be coated with sealing glue.

NO.	Name	Material
-1	Body	BRASS
2	Disc	BRASS
3	Hinge pin	BRASS
4	Valve nut	BRASS
5	Screw	BRASS








JS-C1106

- Before assembling, all parts should be clean, no oil or grease, remove all burrs and sharp edges.
- 2.Before connecting, body cap male thread should be coated with sealing glue.



NO.	Name	Material
1	Body	BRASS
2	Plug	Stainless steel ansi 304
3	Filter	BRASS
4	Gasket	BRASS
4	N 200-0-3-Decovery	BRASS

DN		В		
1/2"	16.5	11.5	57.3	40
3/4"	23.8	11.5	68	47.5
1	29	14	74	51.5
1-1/4"	38	15	94	66
1-1/2"	42	19.5	102	81.5
2"	51	20	123	92
2-1/2"	65	21	135	105
3"	77	21.5	155	122
4"	95	21.5	183	149

DN	A	le le	E	
1/2"	6	70	250	
3/4"	10	77.5	285	
1"	10	87	310	
1-1/4"	12.5	94	310	
1-1/2"	14.5	131	525	
2"	15	138.5	525	

JS-C1201

- Before assembling, all parts should be clean, no oil or grease, remove all burrs and sharp edges.
- 2.Before connecting, body cap male thread should be coated with sealing glue.

NO_	Name	Material
1	Body	BRASS
2	Rubber gasket	NBR
3	Nut	BRASS
4	Rubber gasket	NBR
5	Cartridge for valve	BRASS
6	Lever	BRASS
7	Peg	BRASS
8	Plastic cover	ABS
9	Nut	BRASS

